



Guidelines to safety harness adjustment:



253-61



After choosing the correct seating position, put the belt on and adjust the lap belt so it fits tightly in the bend between the pelvic crest and the upper thigh. The release buckle should be located in the center in front of your body



close buckle



tighten lap belt



WRONG

